



Corporate Office: PerTronix Inc. 440 E. Arrow Highway, San Dimas, California 91773 \* Phone 909.599.5955 • FAX 909.599.6424

## Installation Instructions and Warranty Information

### 40-3115 ~ 2015 Chevy Camaro V8 Axle Back



 **WARNING**

This product can expose you to chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov/product](http://www.P65Warnings.ca.gov/product)

PerTronix© thanks you for choosing JBA HEADERS, the best fitting, highest quality header on the market. In order to realize the full potential of our good fit, please read and understand these instructions completely prior to starting work.

Check to make sure you received the proper parts for your application. The header number will be stamped on the engine flange. If you are unsure you have received the proper parts call before you start work.

Be sure to work safe! Whenever you work under the vehicle be sure that it is located on level, solid ground and is supported by adequate safety stands! Remember: Hot asphalt will not support most jack stands!

1. Place vehicle in a location where the floor is solid and flat, with adequate lighting. Do not attempt to work on a hot engine. Heat causes metal to expand and makes removal of fasteners difficult at best. Disconnect the battery cables from the battery. Raise the front of the vehicle to obtain adequate access to the bottom exhaust manifold flanges. Use large-base jack stands to support the vehicle. Do not rely on the jack! Block the tires to prevent the vehicle from rolling off the jack stands.

2. Using a Sawzall or similar tool, cut the factory exhaust pipe in line with the rear differential cover as seen in the picture.



3. Spray WD40 or similar on all bolts and the rubber hangers, remove the rubber hangers from the factory exhaust mufflers. Slide the hangers off the rubber mounts and remove the muffler from the car.

3. Install the JBA Mufflers by slipping the pipe over the section you cut (with the clamp installed) and slip the hangers into the factory rubber mounts. Do not tighten the clamps at this time.

4. Align the mufflers so that the tips are centered in the rear valance, keeping as much distance between the muffler and the rear most hanger as possible (otherwise a rattle might ensue). Once you are happy with the fitment, tighten all clamps.

5. Start the car and check for leaks. JBA recommends that you retighten the clamps after 100 miles.

Parts List:

(2) JBA Axle Back Pipes

(2) Clamps



### LIMITED ONE YEAR WARRANTY

All JBA HEADERS and exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.

**JBA**  
performance**exhaust**®



