

JBA[®] performance exhaust

Corporate Office: PerTronix Inc. 440 E. Arrow Highway, San Dimas, California 91773 * Phone 909.599.5955 • FAX 909.599.6424

Installation Instructions and Warranty Information

6012S/36012S 2007-14 Toyota Tundra 5.7



3

This product is Not legal for Street or Off Highway use in California or in states that have adopted California Emissions Regulations and is only intended for Closed Course Competition use, except 1965 and Older US manufactured California Certified vehicles, 1967 or older US manufactured Federally Certified vehicles, or 1967 and older Foreign manufactured vehicles which may have any aftermarket add-on or modified part installed as long as the vehicle can still meet the tailpipe emission standards for the year of the vehicle and retain any original or retrofit crankcase control (PCV) devices and NOx device required for the year of the vehicle.

Read all instructions carefully before attempting installation.

WARNING

This product can expose you to chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov/product

REV.4 6-6-17 DSL

PerTronix© thanks you for choosing JBA HEADERS, the best fitting, highest quality header on the market. In order to realize the full potential of our good fit, please read and understand these instructions completely prior to starting work.

Check to make sure you received the proper parts for your application. The header number will be stamped on the engine flange. If you are unsure you have received the proper parts call before you start work.

Be sure to work safe! Whenever you work under the vehicle be sure that it is located on level, solid ground and is supported by adequate safety stands! Remember: Hot asphalt will not support most jack stands!

Many factors affect the installation of headers, some of which are broken or aftermarket motor mounts, accidents that impact the configuration of the frame, and/or the installation of different engines or aftermarket cylinder heads.

Attention Customers breaking in new engines: Due to the extreme heat generated during the break-in process, the appearance of the ceramic coating may be altered in certain areas. The protection characteristics and thermal barrier properties of the coating is never compromised. It is recommended that a cast iron manifold or old set of headers be used for this process.

Notice: The coating of these headers can be marred or scratched during installation. If the header needs to be returned and is damaged, you will be charged for recoat.

JBA uses sealing beads on all its headers. We have found that when installed correctly, the raised bead around each port increases the pressure exerted on the gasket directly adjacent to the port and effectively prevents leaking gaskets. It is normal for the flange to be raised off the cylinder head the thickness of the sealing bead. It is important when installing the header, to install all bolts loosely, then tighten evenly to ensure the flat installation of the flange. The torque sequence from one flange to another will vary, but generally every bolt on a header should be first fit snug, starting from the inside of the flange working out, alternating from top to bottom so that the bolt connects the flange to the manifold to the point where they barely touch. Second, using the same inside-out pattern, tighten each bolt until finished. This method will help prevent leakage and will give the user the best possible performance out of their pair of headers.

1. Place vehicle in a location where the floor is solid and flat, with adequate lighting. Do not attempt to work on a hot engine. Heat causes metal to expand and makes removal of fasteners difficult at best. Disconnect the battery cables from the battery. Raise the front of the vehicle to obtain adequate access to the bottom exhaust manifold flanges. Use large-base jack stands to support the vehicle. Do not rely on the jack! Block the tires to prevent the vehicle from rolling off the jack stands.
2. Spray WD-40 or some type of penetrating oil on all accessible fasteners and fittings before attempting to remove them.
3. On 4WD vehicles you will need to remove the front drive shaft from the differential.
4. From underneath the vehicle disconnect the exhaust system from the exhaust manifolds by unbolting the (3) bolts at the collectors. Unbolt the Y Pipes that connect the catalytic converters to the exhaust system and remove from the truck.
5. On the passenger side remove the (4) bolts attaching the heat shields to the factory manifold.

6. Unplug the O2 sensor from its harness
7. Remove the nuts attaching the air tube to the manifold. Loosen the air tube on the drivers side to allow some flexibility. Remove the nuts attaching the factory manifold to the cylinder head. Remove the manifold; retain the air tube gasket, and nuts.
8. Remove the gaskets and any gasket material or any carbon deposits that remain on the head surface. The use of a gasket removal agent or scraper will ease the removal of any gasket material.
9. Transfer the O2 sensor from the factory manifold to the new passenger side header. Apply a small amount of anti-seize to the threads for the sensor before installing it in the new header.
10. Install the new JBA Header using the supplied gasket and original fasteners. Torque to 33 ft./lbs. Re-connect the air tube, but do not tighten.
11. Remove the (4) bolts attaching the heat shields to the driver side factory manifold.
12. Unplug the O2 sensor from its harness. Unbolt the dipstick bracket from the head and remove the dipstick tube.
13. Remove the nuts attaching the air tube to the manifold. Remove the nuts attaching the factory manifold to the cylinder head. Remove the manifold; retain the air tube gasket, and nuts.
14. Remove the gaskets and any gasket material or any carbon deposits that remain on the head surface. The use of a gasket removal agent or scraper will ease the removal of any gasket material.
15. Transfer the O2 sensor from the factory manifold to the new driver side header. Apply a small amount of anti-seize to the threads for the sensor before installing it in the new header.
16. Install the new JBA Header using supplied gasket and original fasteners. Torque to 33 ft./lbs. Re-connect the air tube, then tighten the passenger side. Re-install the dipstick tube.
17. if you are using the JBA Mid Pipe, attach it to the header collectors and the stock or JBA exhaust system. If you are Not using the JBA Mid Pipe, you will need to fabricate your exhaust from the headers back.
18. Reconnect O2 sensors and re install the front drive shaft on 4WD models.
19. Check to insure adequate clearance between header and shifter cable (small cable that runs from firewall, to brace on fender well, to transmission). More clearance can be gained by adjusting (bending) brace on fender well.
20. Start the engine and let it warm up Check for leaks. Shut engine off and let it cool down. Check to make sure all fasteners are tight.
21. All tubular headers require maintenance including periodically checking and retightening of the header bolts.

Parts List:

- (1) Driver Side Header Assembly
- (1) Passenger Side Header Assembly
- (2) Head Flange Gaskets
- (2) V-Band Clamps
- (2) V-band reducers
- (2) O2 Sensor plugs

LIMITED ONE YEAR WARRANTY

All JBA HEADERS and exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.



